

Installation instructions for window guards

E-Flex[®]

The purpose of the window guards is to help prevent break-in attempts into the van's cargo area. Please read these installation instructions carefully before beginning the installation.

1. First, make sure the window guard is facing the correct way and bend all mounting tabs inward (use pliers if needed). Place the window guard into the window recess. Handle with care to avoid damaging the vehicle's paintwork. Protect the painted surface if necessary.



2. Attach the guard to the vehicle using the included self-drilling screws. At first, fasten the screws loosely, as they will be removed later.



3. Remove the screws one at a time and apply a small amount of installation adhesive (not included) to the tip of each screw. Then reinsert the screws and tighten them firmly, but not too tightly, to avoid stripping the threads.



The installation is now complete. Finally, you can attach the included E-Flex window guard sticker to the outside of the glass. On tinted windows, the sticker serves as a warning to potential intruders that breaking in is not worth the effort.

TIP: If the window guard rattles against the vehicle's metal surface after installation, place a small piece of padding (e.g., a piece of cardboard) in between to eliminate the noise.